



Accessories

SERVICE 		9 <hr/> 19800079
--	--	-----------------------------------

IPL, Lawn Sweeper 32", 38", 1998-09, Art. nr. 106 25 36-61

Lawn Sweeper 32", 38"

Spare parts


Ersatzteile

Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar



REPAIR PARTS FOR LAWSWEEPER 32", 38"

1	5310074-09	Hitch Tube RH, 32"	48	5310027-43	Wheel Drive Housing Assy RH
1	5310074-10	Hitch Tube RH, 38	49	5310076-03	Upper Hopper Frame Tube RH, 32"
2	5310074-11	Hitch Tube, 32"	49	5066238-01	Upper Hopper Frame Tube RH, 38"
2	5310074-12	Hitch Tube, 38"	50	5310076-02	Upper Hopper Frame Tube LH, 32"
3	5310028-08	End Plate LH	50	5066239-01	Upper Hopper Frame Tube LH, 38"
4	5310028-09	End Plate RH	51	5310076-04	Lower Hopper Frame Tube RH, 32"
5	5310074-13	Wrapper, 32"	51	5066242-01	Lower Hopper Frame Tube RH, 38"
5	5310074-14	Wrapper, 38"	52	5310076-05	Lower Hopper Frame Tube LH, 32"
6	5310074-15	Rear Support Brace	52	5066243-01	Lower Hopper Frame Tube LH, 38"
7	7227870-03	Rivet	53	5310076-14	Bag Frame Strap, 32"
8	5310076-17	Skirt, 32"	53	5066215-01	Bag Frame Strap, 38"
8	5066222-01	Skirt, 38"	54	5066244-01	Hopper Support Rod
9	5310076-09	Skirt Retainer, 32"	55	5310027-34	Hopper Rope
9	5310076-09	Skirt Retainer, 38"	56	5310076-09	Bag Retainer, 32"
10	5310074-18	Height Adjustment Assy , 32"	56	5066209-01	Bag Retainer, 38"
10	5310074-19	Height Adjustment Assy , 38"	57	5310028-28	Height Adjustment Strap
11	5310028-15	Curved Hd. Bolt	58	5310027-72	Hitch Bracket
12	5310028-16	Washer Bowed	59	5066212-01	Hitch Bracket
13	7351164-05	Lock Washer	60	5310028-31	Height Adjustment Handle
14	8732205-00	Nut, Hex	61	5310074-23	Bag Arm
15	5066202-01	Brush Bushing Assy	62	5310074-24	Hopper Bag Pivot Rod, 32"
16	5310028-17	Boll Bearing	62	5310074-25	Hopper Bag Pivot Rod, 38"
17	5066204-01	Bearing Retainer	63	5310027-46	Wheel & Tire Assy
18	5310076-15	Brush Shaft 32"	64	5066254-01	Wheel Bearing
18	5066205-01	Brush Shaft 38"	65	5310028-34	Bolt, Hex
19	5310074-20	Brush 32"	66	5310028-35	Bolt, Hex
19	5310074-21	Brush 38"	67	5310076-16	Nut, Hex
20	7292370-51	Bolt Hex	68	5310028-36	Spacer Bushing
21	5310076-29	Nut	69	7341152-01	Washer
22	5066206-01	Brush Retainer (Double)	70	5066260-01	Knob, Wing
23	5066207-01	Brush Retainer (Single)	71	8721405-06	Carriage Bolt
24	5310027-41	Washer	72	7341164-01	Washer
25	5066217-01	Sprocket Gear	73	5310074-26	Hex Bolt
26	5066218-01	Dust Cover	74	5066264-01	Rubber Grip
27	5066219-01	Pawl	75	5310028-39	Tooth Lock Washer
28	5066323-01	Retaining Ring	76	5066256-01	Hitch Pin
29	5066224-01	Retaining Ring	77	5066265-01	Hitch Adjustment Tube
30	5066225-01	Shim Washer	78	7216802-51	Hairpin Cotter
31	8747805-12	Bult Hex	79	5066267-01	Hopper Mount Clamp
32	7341173-41	Flat Washer	80	5310028-40	Palnut
33	7341172-01	Washer	81	7252372-51	Bolt
34	5066247-01	Flat Washer	82	7252374-71	Hex Bolt M6
35			83	7252329-51	Bolt
36	5066229-01	Hex Lock Nut	84	7322114-01	Hex Lock Nut
37	5066230-01	Hub Cap	85	5066253-01	Hex Bolt
38	5066231-01	Ring, Retaining	86	8736806-00	Hex Lock Nut
39	5066233-01	Bolt Hex	87	5310028-38	Hex Bolt
40	5066266-01	Washing Spacer	88	5310046-37	Hairpin Cotter
41	5310027-99	Sprocket Ratchet .RH (Not shown)	89	5310046-38	Clevis Pin
42	5066235-01	Sprocket-Ratchet L.H	90	5310076-06	Hopper Bag, 32"
43	5066236-01	Washer	90	5066240-01	Hopper Bag, 38"
44	5310027-45	Roller Chain	91	5310076-07	Wind Screen, 32"
45	5310028-21	Bolt, Hex	91	5066241-01	Wind Screen, 38"
46	5310076-26	Bolt, Hex		5310074-50	Owners Manual
47	5310027-44	Wheel Drive Housing Assy LH			