


**Jonsered**



**Service Tools, 2000-08**

**Not available as printed IPL**

# Service Tools

# HAND TOOLS



## Z ALLEN KEY

For screws in limited spaces . 4 mm

Order no. 502 71 36-01



## COMPRESSOR KIT

To compress piston ring(s)

Order no. 502 50 70-01



## T-HANDLE WRENCH SET

Set includes T-handle Allen wrenches of 3, 4, 5 and 6 mm and one Hex wrench, 8 mm

Order no. 504 90 00-06





# HAND TOOLS



## T-HANDLE ALLEN KEY

3/16" **Order no. 502 50 57-01**



4 mm. **Order no. 502 50 18-01**



5 mm **Order no. 502 50 64-01**



6 mm. **Order no. 504 90 00-01**



Modell: 625, 630, 670

3 mm. **Order no. 502 50 19-01**



## T-HANDLE SOCKET WRENCH

8 mm. **Order no. 505 38 13-08**



10 mm. **Order no. 502 50 23-01**



## TORX SCREWDRIVER, T20

**Order no. 502 51 67-01**

# HAND TOOLS

## ALLEN SCREWDRIVER



3 mm.

Order no. 502 50 86-01



4 mm.

Order no. 502 50 87-01



5 mm.

Order no. 502 50 88-01



## PISTON STOP, METAL

Order no. 504 91 06-05



## PISTON STOP, METAL

For engines over 80 cc

Order no. 502 50 33-01



## PISTON STOP, PLASTIC

For smaller engines.

Order no. 502 54 15-01





# TESTING - IGNITION SYSTEM



## IGNITION PLIERS

For piercing spark plug lead

Order no. 502 50 06-01



## AIRGAP TOOL 0,3 MM

To ensure proper gapping of ignition coil

Order no. 502 51 34-05



# TESTING - PRESSURE TEST



## VACUUM TESTER

Order no. 502 50 37-01



## PRESSURE GAUGE

Order no. 502 50 38-01



## COMPRESSION TESTER

Order no. 531 03 16-86



## RUBBER WEDGE

For pressure testing

Order no. 502 54 11-02



## RUBBER WEDGE

Order no. 502 54 11-01



## SPARK PLUG ADAPTER

For pressure testing

Order no. 503 84 40-02



# TESTING - CARBURETTOR/FUEL SYSTEM



## CARB INTAKE BOOT ASSEMBLY TOOL

Order no. 502 54 17-01



## FUEL LINE TOOL

Assists in fuel line retrieval



Order no. 502 50 83-01



## CARBURETOR ADJUSTMENT SCREWDRIVER

For use with CARB/EPA units

Order no. 531 00 48-63



## LIMITER CAP INSTALLATION TOOL

For use with CARB/EPA units

Order no. 530 03 11-60



# TESTING - FLYWHEEL/CLUTCH/OIL PUMP

## FLYWHEEL REMOVAL TOOL



Order no. 502 51 49-02



## CLUTCH REMOVAL TOOL

Model: 2145, 2150, 2149



Order no. 502 54 16-01



## CLUTCH REMOVAL TOOL

Model: 2063, 2065, 2071, 2163, 2165, 2171



Order no. 502 52 22-01



## CLUTCH REMOVAL TOOL

Model: 2077



Order no. 502 54 04-01



## CLUTCH REMOVAL TOOL

Model: 2063, 2065, 2071, 2163, 2165, 2171

Correction: 2156, 2159



Order no. 502 52 22-02





# TESTING - FLYWHEEL/CLUTCH/OIL PUMP



## OILER REMOVAL TOOL

Model: 2035


Order no. 530 03 11-66



## OIL GEAR REMOVAL TOOL

Model: 2077

Order no. 502 54 09-01



## REMOVAL TOOL

For use with mini saw mill 6000+

Order no. 531 01 96-76



## CLUTCH DRUM REMOVAL TOOL

Model: GR 2022, 2026, 2032, 2036, RS 52

Order no. 502 52 16-01



## FLYWHEEL REMOVAL TOOL

Order no. 504 91 08-03



# TESTING - FLYWHEEL/CLUTCH/OIL PUMP



**FLYWHEEL REMOVAL TOOL**

Order no. 502 51 94-01



**FLYWHEEL REMOVAL TOOL**

Order no. 504 91 08-07



**CLUTCH SPRING INSTALLATION TOOL**

Order no. 502 50 49-01





# CRANKCASE/CRANKSHAFT



**BEARING PULLER TOOL**

Order no. 504 90 90-02



**CRANKCASE SPLITTER TOOL**

Order no. 502 51 61-01



**CRANKCASE SEAL REMOVAL TOOL**

Model: 2063, 2065, 2071, 2163, 2165, 2171

Order no. 504 91 40-01



**CRANKSHAFT SEAL REMOVAL TOOL**

Model: 2149

Order no. 504 91 40-02



# CRANKCASE / CRANKSHAFT



## SEAL PROTECTOR TOOL

Model: 2077, 2083, 2095

Order no. 502 50 52-01



## SEAL PROTECTOR TOOL

Model: 2141, 2145

Order no. 502 54 20-01



## SEAL PROTECTOR TOOL

Model: 625, 630, 670

Order no. 502 50 53-01



## SEAL PROTECTOR TOOL

Model: 2041, 2045

Order no. 505 38 17-23



# CRANKCASE / CRANKSHAFT



## CRANKSHAFT INSTALLATION TOOL

Model: 2063, 2065, 2071, 2163, 2165, 2171

Order no. 502 50 30-15



## CRANKSHAFT INSTALLATION TOOL

Model: 625, 630, 670

Order no. 502 50 30-04



## CRANKSHAFT INSTALLATION TOOL

Model: 2083

Order no. 502 50 30-14



## SEAL INSTALLATION TOOL

Model: 625, 630, 670

Order no. 502 51 69-01



## CRANKSHAFT INSTALLATION TOOL

Model: 2041, 2045

Order no. 505 38 17-26



## CRANKSHAFT SEAL INSTALLATION TOOL

Model: 2063, 2065, 2071, 2163, 2165, 2171.

Order no. 502 52 21-01



# CRANKCASE / CRANKSHAFT



## CRANK SHAFT INSTALLATION TOOL

Model: 2077

Order no. 502 50 30-13



## SEAL RING INSTALLATION TOOL

Order no. 502 50 79-01



## SEAL RING INSTALLATION TOOL

Model: 2095

Order no. 502 50 82-01



## SEAL RING INSTALLATION TOOL

Model: 2041, 2045

Order no. 502 52 20-01



## CRANKCASE ASSEMBLY TOOL

Model: 2149

Order no. 502 54 18-01



## SEAL RING REMOVAL TOOL

Model: 2063, 2065, 2071, 2163, 2165, 2171.

Order no. 502 50 55-01



# AV-SYSTEM



## AV REMOVAL TOOL, 14 MM

Model: 625, 630, 670

Order no. 502 51 00-02



## AV REMOVAL TOOL, 11 MM

Model: 625, 630, 670


Order no. 502 50 67-01



## AV REMOVAL TOOL, 18 MM

Model: 625, 630, 670

Order no. 502 50 66-02



## AV REMOVAL TOOL

Model: 2065, 2071, 2063, 2165, 2171.

Order no. 502 52 18-02





# CHAIN BRAKE



## FIXTURE BRAKE BAND

Model: 2054, 2055



Order no. 502 71 30-01







# CLEARING SAW/TRIMMER - GEAR HEAD



## RETAINING RING REMOVAL TOOL

Model: RS 45, RS 50, RS52

Order no. 502 52 17-01



## FITTING SLEEVE

Model: RS 53, RS 44, GR 50, GR 41.

Order no. 502 52 15-01






# CHAIN



## CHAIN SHARPENING MACHINE

Order no. 508 23 26-53



## CHAIN BREAKER TOOL

Order no. 531 01 27-11





# CHAIN



## CHAIN SPINNER TOOL

Order no. 531 01 27-12



## GRINDING DISC 5 MM

For 3/8" and .404" chains

Order no. 508 23 26-60



## GRINDING DISC 3 MM

For .325" chains

Order no. 508 23 26-60



# LUBRICANTS/SEALANTS



## SILICON SEALANT

Order no. 532 14 81-42



## SILICON SEALANT

Order no. 503 26 70-01





# SHOP AIDS



**POWER HEAD HOLDER  
(CHAIN SAWS)**

Order no. 502 51 02-01



7 391883 052686



**TRIMMER CLAMP TOOL**

Order no. 502 51 03-01



7 391883 052624



# OTHERS

## TOOL KIT FOR CHAIN SAWS



Order no. 503 55 85-01



## PULLER

Order no. 502 50 26-01





**TACHOMETER**

Order no. 502 71 14-01



**CRANKSHAFT INSTALLATION TOOL**

Model: 2149

Order no. 502 70 45-06



# WORKSHOP MANUAL



## WORKSHOP MANUAL

For model 2063, 2065, 2071

**Swedish**

Order no. 108 87 60-01

**English**

Order no. 108 87 60-26

**French**

Order no. 108 87 60-31

**Spanish**

Order no. 108 87 60-46

**German**

Order no. 108 87 60-51



## WORKSHOP MANUAL

For model 2149

**Swedish**

Order no. 108 87 81-01

**Finnish**

Order no. 108 87 81-11

**English**

Order no. 108 87 81-26

**German**

Order no. 108 87 81-51

**French**

Order no. 108 87 81-31

**Spanish**

Order no. 108 87 81-46

**Italian**

Order no. 108 87 81-41



## WORKSHOP MANUAL

For tractors  
All models.

**English**

Order no. 108 07 15-04

\_\_\_\_\_

\_\_\_\_\_