

B22

Tanaka

TBC 270PF/PFD


B22

02

TBC-270PF,PFD CRANK CASE


Parts List

Ref.	Part No.	Description	Q'ty	Serial No.
019	330-00200-21	GEAR SHAFT SHIM 0.10	V	
019	330-00200-22	GEAR SHAFT SHIM 0.15	V	
019	330-00200-23	GEAR SHAFT SHIM 0.20	V	
019	330-00200-24	GEAR SHAFT SHIM 0.30	V	
021	991-01080-011	HEX. NUT 8	1	
022	798-01630-20	STARTER PULLEY	1	
026	359-10112-20	CLUTCH WASHER B	1	
031	072-01680-90	CRANK CASE ASS'Y	1	
032	999-66122-200	OIL SEAL TB 12227	2	
033	999-61600-100	BALL BEARING #6001, 28MM/OD	2	
034	090-01680-20	CRANK CASE GASKET	1	
036	994-14050-251	SCREW 5X25/S	2	
037	990-11050-381	SCREW 5X38	2	
038	992-10050-012	S.WASHER 5	2	
051	155-21743-80	MAGNETO ROTOR COMP.	1	
052	992-00080-011	SMALL WASHER 8	1	
054	991-01080-011	HEX. NUT 8	1	



B22
03-1

TBC-270PF,PFD ENGINE-1




Parts List

Ref.	Part No.	Description	Q'ty	Serial No.
041	403-0097A-21	INTAKE MANIFOLD GASKET	1	
042	404-0097A-90	CARB. INSULATOR SET, SPARE	1	
045	994-16050-241	SCREW 5X24WS	2	
046	402-0602K-21	CARBURETOR GASKET	1	
050	455-01680-91	CARBURETOR SET, SPARE	1	
053	436-0162V-20	CLEANER BASE	1	
054	528-01680-20	CHOKE VALVE 1.5	1	
055	999-67008-012	O-RING S-8	1	
056	470-0602N-20	CLEANER COLLAR	1	
057	423-0637C-80	CLEANER BODY COMP.	1	
058	992-00050-011	SMALL WASHER 5	2	
059	992-10050-012	S.WASHER 5	2	
060	990-11050-602	SCREW 5X60	2	
061	446-0637C-20	CLEANER SPONGE	1	
062	452-01680-90	CLEANER COVER SET	1	
063	380-0637C-20	SPECIAL SCREW	1	
068	659-04300-20	COLLAR C	3	
070	442-25143-80	PRIMING PUMP COMP.	1	
071	595-01682-90	TANK CAP ASS'Y	1	
073	626-32550-20	TANK CAP CHAIN	1	
075	649-01680-20	TANK FIXING COLLAR	1	
076	994-63050-204	HEX.HOLE BOLT 5X20PS	2	
077	940-04300-20	ENGINE BED	1	
078	700-02504-08	FUEL PIPE 2.5X4X80	2	
079	534-32710-20	RETURN GROMMET	1	
080	992-01050-061	WASHER 5	1	
081	994-61050-304	HEX. HOLE BOLT 5X30S	1	
086	223-0162V-90	FUEL PIPE ASS'Y	1	
087	680-00731-20	CLIP, 6.3 DIA.	1	
089	675-04042-80	PUMP FILTER BODY COMP.	1	
091	591-01685-20	FUEL TANK, VERMILION	1	
121	564-00070-91	AIR VENT ASS'Y	1	
122	405-36152-22	AIR VENT PIPE	1	
123	646-3252L-90	AIR VENT VALVE ASS'Y	1	
		SEE NEXT PAGE	1	

B22
10

TBC-270PF,PFD OPERATION PIPE(PFD W110987-)



Parts List

Ref.	Part No.	Description	Q'ty	Serial No.
001	343-37300-20	DRIVE SHAFT, 7X1504L SOLID	1	
002	341-37378-80	DRIVE SHAFT PIPE COMP.	1	
003	347-37356-90	BUSHING ASS'Y	5	
042	335-37307-20	LIFTING METAL, 90 DGR SWIVEL	1	
043	334-37352-21	LIFTING METAL COLLAR 26	2	
044	994-62050-304	HEX. HOLE BOLT 5X30.P	2	
046	315-37304-20	SPECIAL NUT	1	
063	165-37590-20	HANDLE GRIP	1	
064	994-61050-254	HEX. HOLE BOLT 5X25/S	4	
066	506-37623-20	HANDLE BRACKET A	1	
067	507-37623-20	HANDLE BRACKET B	1	
068	510-37352-20	CUSHION RUBBER	1	
069	508-37623-20	HANDLE BRACKET C	1	
071	994-81060-254	HEX. HOLE BUTTON SCREW 6X25S	2	
072	336-33411-82	CUSHION PAD COMP.	1	
074	460-33111-20	CLAMP B.	1	
075	502-37415-21	LEFT HANDLE	1	
084	164-07086-50	PROTECTION TIBU	1	
091	746-37455-91	SHOULDER BELT ASS'Y,CR/DOUBLE	1	
092	501-37822-20	RIGHT HANDLE	1	
095	870-38401-90	THROTTLE LEVER ASS'Y, 19 DIA.	1	
098	253-38400-20	SAFETY LEVER	1	
100	832-38400-20	RETURN SPRING	1	
101	880-38401-20	THROTTLE LEVER	1	
103	322-38400-20	BLIND PLUG	1	
106	993-46040-202	SCREW 4X20, BLACK	2	
107	994-31050-303	SCREW 5X30, BLACK	1	
108	991-01050-043	CONTAL NUT 5	1	
110	156-38401-80	STOP SWITCH	1	
120	887-38401-80	THROTTLE WIRE	1	
125	885-38400-80	THROTTLE WIRE COMP.	1	

B22
15

TBC-270PF,PFD TOOLS

Parts List

Ref.	Part No.	Description	Q'ty	Serial No.
030	813-20000-20	HEX. WRENCH 4	1	
031	826-20000-80	COMBI, BOX WRENCH 17X19	1	
035	615-37224-20	CUTTER COVER	2	

