


H39

Tanaka

THT 210S

H39
08

THT-210S GEAR CASE/BLADE



Parts List

Ref.	Part No.	Description	Q'ty	Serial No.
001	300-33290-80	GEAR CASE COMP.	1	
002	993-50015-002	STOP RING C-15, OUTER	1	
003	999-61600-200	BALL BEARING #6002, 32MM/OD	1	
004	999-61600-202	BALL BEARING #6002Z, 32MM/OD	1	
005	288-33180-80	CLUTCH DRUM COMP.	1	
007	075-33160-20	GUIDE PLATE	1	
008	101-33190-20	CAM ROD	2	
009	292-33194-80	GEAR 2 COMP.	1	
010	303-33160-20	GEAR CASE GASKET	1	
011	630-33165-20	GEAR CASE COVER	1	
012	122-33248-20	CUTTER GUIDE 734L M6	1	
013	136-33160-20	PROTECTION PLATE	1	
014	990-52060-165	HEX HOLE FLUSH SCREW 6X16	2 - A088150	
014	990-52060-255	HEX. HOLE FLUSH BOLT 6X25	2 A088151 -	
015	120-33168-21	CUTTER A (696.5L)	2	
016	085-33160-20	GREASE SEAL A	2	
017	129-33202-20	WASHER 7 BLACK	5	
018	124-32287-20	FIXING BOLT A M6	5	
019	991-82060-001	FLANGE NUT 6	5 - A088150	
019	991-82060-001	FLANGE NUT 6	4 A088151 -	
021	994-61040-124	HEX. HOLE BOLT 4X12S	6	
022	300-32250-80	GREASE NIPPLE COMP.	1	
023	994-61060-184	HEX. HOLE BOLT 6X18/S	2	
030	462-33290-20	SUPPORT PLATE	1 A088151 -	
032	991-87060-001	UPS-P NUT 6	3 A088151 -	
033	992-01060-011	WASHER 6	3 A088151 -	
060	301-33160-21	GEAR CASE B	1	
069	138-33171-20	CUTTER COVER	1	
072	994-40060-011	SPRING NUT 6	2	
082	994-61040-104	HEX. HOLE BOLT 4X10S	2	
083	135-33191-20	GUARD PLATE	1 - A088150	
088	999-61608-013	BALL BEARING 608 ZZ C3	1	

H39
09

THT-210S TOOLS

Parts List

Ref.	Part No.	Description	Q'ty	Serial No.
075	036-29331-50	COMBI. BOX SPANNER 10X19 ,PLUS	1	
076	813-20000-20	HEX. WRENCH 4	1	

