

IPL, Spike Aerator, Scarifier, 2007-01, 504 05 45-05

45-0346, 964 99 57-03

Spike Aerator 45-0346

Scarifier

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

SPIKE AERATOR MODEL 45-0346 REPAIR PARTS



KEY NO.	PART NO.	QTY.	DESCRIPTION	KEY NO.	PART NO.	QTY.	DESCRIPTION
1	531 00 81-01	1	Tray	15	531 00 81-11	1	Bracket ,axle
2	531 00 81-02	1	Plate, lift	16	531 00 81-12	1	Lift handle
3	531 00 81-03	12	Disk	17	531 00 46-30	2	Arm. Hitch mount
4	531 00 76-30	12	Hub, spike disk	18	531 00 46-31	3	Bracket Hitch mount
5	504 06 08-01	9	Spacer, 2.13"long	19	504 06 10-01	3	Wheel
6	504 06 09-01	10	Spacer,1/2" long	20	504 06 11-01	2	Bolt
7	531 00 81-06	1	Axle	21	531 00 81-15	2	Bracket, angle
8	531 00 81-07	2	End plate	23	501 33 27-01	4	Nut
9	531 00 81-08	2	Cotter Pin	26	874 76 05-32	2	Bolt
10	531 00 74-26	23	Bolt	27	531 00 81-17	2	Bolt
11	501 33 26-01	31	Nut	28	721 68 02-51	2	Bolt
12	531 00 27-01	10	Washer	29	531 00 81-18	1	Pin, Hair cotter
13	531 00 81-10	1	Bracket, axle support	30	506 62 64-01	1	Pin, Hitch (Flat head)
14	531 00 46-42	2	Bracket, hitch	31	872 11 05-08	4	Bolt