

LM2150 SM

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

ROTARY LAWN MOWER - - MODEL NUMBER LM2150SM (96111002400) PRODUCT NUMBER 961 11 00-24



ROTARY LAWN MOWER - - MODEL NUMBER LM2150SM (96111002400) PRODUCT NUMBER 961 11 00-24

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 41 86-10	Control Bar	29	532 40 16-29	Spacer
2	532 19 47-88	Rope Guide	30	- - -	Engine, Briggs & Stratton, Model Number 9T502 (order parts from engine manufacturer)
3	532 12 50-78	Engine Washer	31	532 40 64-28	Selector Spring
4	532 19 60-26	Upper Handle	32	532 08 78-77	Selector Knob
5	532 15 50-44	Lower Handle	33	532 40 78-71	Axle Arm Assembly
6	532 13 20-04	Nut, Hex	34	532 40 16-30	Washer, Curved, Cylindrical
7	532 19 15-74	Handle Bolt 5/16-18 x 1-3/4	35	532 40 16-38	Shoulder Bolt
8	532 12 51-62	Up-Stop Bracket	36	532 19 70-25	Wheel & Tire Assembly
9	532 08 58-25	Screw	37	532 40 91-48	Nut, Hex
10	532 70 08-92	Engine Zone Control Cable	38	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
11	532 75 06-34	Nut, Hex	39	532 41 77-97	Kit, Lawn Mower Housing
12	532 06 64-26	Wire Tie	40	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
13	532 05 17-93	Hairpin Cotter	41	532 14 97-41	Thread Cutting Screw 5/16-18 x 3/4
14	532 19 19-38	Wing Nut, Steel	42	532 18 21-66	Danger Decal
15	532 41 35-68	Discharge Guard	43	873 93 05-00	Locknut, Hex 5/16-18
16	532 85 02-63	Helical Lockwasher 3/8	44	532 19 79-91	Clip, Cable
17	532 06 91-80	Nut, Hex	45	532 08 38-16	Screw #10
18	532 85 10-74	Hardened Washer	46	532 11 11-90	Clamp, Cable
19	532 41 18-32	Torsion Spring	47	532 70 04-17	Control Throttle
20	532 14 51-06	Blade, 20"	48	532 18 33-65	Screw 1/4-20 x 2.12
21	532 08 86-02	Bracket, Mounting	55	532 14 15-19	Front Baffle
22	532 15 02-15	Hinge Rod	56	873 80 04-00	Nut, Hex
23	532 15 41-47	Footguard	57	532 41 24-00	Mulcher Plug
24	532 41 08-07	Wheel Adjusting Bracket	--	532 14 15-20	Rear Baffle (not shown)
25	532 85 09-77	Blade Adapter	--	532 41 77-92	Operator's Manual, European
26	532 17 09-75	Handle Bracket Assembly, RH	--	532 41 77-91	Operator's Manual, Scandinavian
27	532 17 09-77	Handle Bracket Assembly, LH	--	532 41 77-94	Operator's Manual, East Bloc
28	532 06 15-37	Washer	--	532 41 77-93	Operator's Manual, Baltic

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.