

LM2150 SM

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

ROTARY LAWN MOWER - - MODEL NUMBER LM 2150SM (96111002402) PRODUCT NUMBER 961 11 00-24



ROTARY LAWN MOWER - - MODEL NUMBER LM 2150SM (96111002402) PRODUCT NUMBER 961 11 00-24

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 41 86-10	Control Bar	30	- - -	Engine, Briggs & Stratton, Model Number 9T502-1322-B1 (order parts from engine manufacturer)
2	532 19 47-88	Rope Guide	31	532 40 64-28	Selector Spring
3	532 12 50-78	Engine Washer	32	532 08 78-77	Selector Knob
4	532 19 60-26	Upper Handle	33	532 40 78-71	Axle Arm Assembly
5	532 15 50-44	Lower Handle	34	532 40 16-30	Washer, Curved, Cylindrical
6	532 13 20-04	Nut, Hex	35	532 40 16-38	Shoulder Bolt
7	532 19 15-74	Handle Bolt 5/16-18 x 1-3/4	36	532 19 70-25	Wheel & Tire Assembly
8	532 12 52-03	Up-Stop Bracket	37	532 40 91-48	Nut, Hex
9	532 08 58-25	Screw	38	532 15 04-06	Hex Head Thread Rolling Screw 3/8-16 x 1-1/8
10	532 85 18-09	Engine Zone Control Cable	39	532 42 82-24	Kit, Lawn Mower Housing
11	532 75 06-34	Nut, Hex	40	532 85 10-84	Hex Head Screw 3/8-24 x 1-3/8 Grade 8
12	532 06 64-26	Wire Tie	41	532 14 97-41	Thread Cutting Screw 5/16-18 x 3/4
13	532 05 17-93	Hairpin Cotter	42	532 18 21-66	Danger Decal
14	532 19 19-38	Wing Nut, Steel	43	873 93 05-00	Locknut, Hex 5/16-18
15	532 41 35-68	Discharge Guard	45	532 08 38-16	Screw
16	532 85 02-63	Helical Lockwasher 3/8	46	532 11 11-90	Clamp, Cable
17	532 06 91-80	Nut, Hex	47	532 42 25-73	Control Throttle
18	532 85 10-74	Hardened Washer	48	532 18 33-65	Screw 1/4-20 x 2.12
19	873 80 04-00	Nut, Hex	55	532 14 15-19	Front Baffle
20	532 14 51-06	Blade, 20"	58	532 05 38-47	Nut, Hex
21	532 16 22-34	Bracket, Hold-Down	59	532 42 82-30	Plate, Closeout
22	874 76 04-12	Screw	60	532 06 91-80	Nut, Hex, with Lockwasher Insert
23	532 15 41-47	Footguard	61	874 96 10-08	Screw, Machine #10-24 x 1/2
24	532 41 05-94	Wheel Adjusting Bracket	- -	532 14 15-20	Rear Baffle (not shown)
25	532 85 09-77	Blade Adapter	- -	532 41 77-92	Operator's Manual, European
26	532 17 09-75	Handle Bracket Assembly, RH	- -	532 41 77-91	Operator's Manual, Scandinavian
27	532 17 09-77	Handle Bracket Assembly, LH	- -	532 41 77-94	Operator's Manual, East Bloc
28	532 06 15-37	Washer	- -	532 41 77-93	Operator's Manual, Baltic
29	532 40 16-29	Spacer			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.