

LM2156 CMDA

Spare parts

Ersatzteile


Pièces détachées

Reserve onderdelen

Repuestos

Reservdelar

ROTARY LAWN MOWER - - MODEL NUMBER LM 2156CMDA (96141022301) PRODUCT NO. 961 41 02-23




ROTARY LAWN MOWER - - MODEL NUMBER **LM 2156CMDA** (96141022301) PRODUCT NO. 961 41 02-23

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 18 45-76	Upper Handle Assembly (Includes Foam Grip)	40	532 43 00-33	Handle Bracket, RH
2	532 42 96-43	Cable, Engine Zone Control / Rear Door Prop	41	532 15 04-06	Screw, Dogpoint 3/8-16 x 1-1/8
3	532 43 00-34	Bracket, Upstop	42	532 19 30-00	Spring, Torsion
4	532 14 50 06	Guide, Cable	43	532 19 17-30	Nut, Hex, Nylock
5	532 06 64 26	Wire Tie	44	532 43 06-72	Kit, Lawn Mower Housing
6	532 18 23-98	Handle Knob, Star	45	532 17 56-50	Rod, Hinge
7	532 75 06-34	Screw #10-24 x 1/2	46	532 42 17-82	Blade Adapter / Pulley
8	532 42 65-05	Control Bar	47	532 42 27-06	Blade, 22"
9	532 42 63-00	Rear Door Assembly	48	532 85 10-74	Washer, Hardened
10	532 42 30-63	Palnut 5/16"	49	532 85 02-63	Washer, Helical
11	532 42 55-75	Hairpin, Door/Handle Pivot	50	532 85 10-84	Screw, Machine, Hex Head 3/8-24 x 1-3/8 Grade 8
12	532 19 19-38	Handle Knob, Standard	51	532 43 05-99	Front Baffle
17	532 42 73-07	Rear Baffle	52	532 18 21-66	Decal, Danger
18	532 13 20-04	Keps Locknut 1/4-20	53	817 00 05-10	Screw, Semi-Gimlett Point 1/4-20 x 1/2
19	532 19 47-88	Rope Guide	54	532 08 83-48	Washer, Flat
20	532 42 24-67	Foot Guard	55	532 19 17-30	Nut, Hex, Flanged 1/4-20
21	532 41 99-49	Spring, Rear Door, LH, Black	56	817 41 13-12	Screw, Hex Washer Head #13 x 3/4
22	532 14 18-41	Screw, Panhead, Torx #20	57	532 15 53-77	Nut, Hex 3/8-16
24	532 41 99-48	Spring, Rear Door, RH, Grey	58	532 42 60-72	Lower Handle
25	532 40 91-49	Nut, Hex, Flanged	59	532 19 15-74	Handle Bolt
26	532 41 99-45	Screw, Door/Handle Pivot	62	532 43 50-59	Belt Retainer
27	532 43 27-47	Wheel & Tire Assembly, Rear	63	532 17 88-48	Screw #10-16 x 5/8
28	872 25 05-05	Bolt, Carriage 5/16-18 x 5/8	64	---	Engine, Briggs & Stratton, Model Number 12S902-1368-EA (order parts from Engine manufacturer)
30	532 41 38-08	Nut, Push	65	532 19 74-80	O-Ring
31	532 43 18-93	Selector Knob	68	532 43 11-34	Kit, Wheel Adjuster, Rear, LH (Includes Knob and Pushnut)
32	532 41 99-44	Latch, Mulcher Door	70	532 18 27-48	Grip, Foam
33	532 42 33-56	Mulcher Door	84	532 42 81-24	Fastener, Push
34	532 42 61-25	Pivot Bracket	96	532 19 79-91	Clip, Cable
35	532 43 11-31	Kit, Wheel Adjuster, Rear, RH (Includes Knob and Pushnut)	--	532 43 04-13	Operator's Manual, European
36	532 17 57-35	Hinge Bracket Assembly	--	532 43 04-15	Operator's Manual, Scandinavian
37	532 42 88-67	Screw, Sems, Thread Cutting 5/16-18 x 3/4	--	532 43 04-14	Operator's Manual, East Bloc
38	532 42 61-29	Discharge Deflector	--	532 43 04-16	Operator's Manual, Baltic
39	532 43 00-39	Handle Bracket, LH			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.

ROTARY LAWN MOWER - - MODEL NUMBER **LM 2156CMDA** (96141022301) PRODUCT NO. 961 41 02-23



ROTARY LAWN MOWER - - MODEL NUMBER **LM 2156CMDA** (96141022301) PRODUCT NO. 961 41 02-23

KEY PART NO.	PART NO.	DESCRIPTION	KEY PART NO.	PART NO.	DESCRIPTION
1	532 43 06-52	Drive Control Assembly (Includes Cable)	26	532 16 34-09	Screw, Hi-Lo Thread #12 x 5/8
2	532 42 96-31	Cover, Drive Control, Upper	28	532 43 26-75	Drive Cover Assembly (Includes Mounting Screw and Pushnut)
3	532 42 03-78	Cam	29	532 40 91-48	Locknut, Hex
4	532 43 38-07	Lever, Drive Control, LH	32	532 19 40-18	Drive Pulley
5	532 42 03-81	Spring	33	532 42 66-09	V-Belt
6	532 18 16-98	Screw	35	532 43 11-24	Kit, Wheel Adjuster, Front, LH (Includes Black Knob and Pushnut)
7	532 42 61-34	Cover, Drive Control, Lower	36	532 42 46-57	Gear Case Assembly, Complete
8	532 17 88-48	Screw	38	532 19 17-30	Locknut, Hex 1/4-20
9	532 42 74-26	Cable, Drive Control	40	532 40 65-58	Spring
10	532 43 32-98	Lever, Drive Control, RH	41	532 43 11-21	Kit, Wheel Adjuster, Front, RH (Includes Black Knob and Pushnut)
11	532 40 25-67	Wheel & Tire Assembly, Front	54	532 43 15-55	Grassbag
12	812 00 00-58	E-Ring	57	532 41 99-51	Frame, Grassbag
13	532 40 38-49	Pinion	80	532 42 11-14	Water Washout Assembly
14	532 18 94-03	Dust Cover	81	532 41 97-35	Fitting, Water Washout
15	532 40 48-45	Pawl, Drive	82	532 41 55-85	Washer, Lock, Internal Tooth
16	532 06 77-25	Washer, Flat 3/8	83	532 41 55-86	Locknut, Hex, with O-Ring
17	532 41 38-08	Nut, Push			
18	532 43 18-95	Selector Knob			
25	532 43 17-11	Belt Keeper			

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm

IMPORTANT: Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.