# ILLUSTRATED PARTS LIST

# MODEL NO. 96051002100
# CUSTOMER CATALOG NO. LT2317 CMA
# PRODUCT NO. 960 51 00-21



# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## DECALS 27




| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 40 03-89 | Decal Warning Sym. CE |
| 2 | 532 19 68-41 | Decal Warning Eng. Sym. |
| 4 | 532 43 98-33 | Decal Replacement |
| 5 | 532 44 26-47 | Decal Wheel Steering |
| 6 | 532 18 04-32 | Decal 100 DBA |
| 7 | 532 44 10-70 | Decal Side Panel |
| 8 | 532 40 11-46 | Decal Warning |
| 9 | 532 43 74-43 | Decal Fender Logo |
| 11 | 532 18 21-66 | Decal Mower Cut Finger Symbol |
| 12 | 532 15 97-37 | Decal Brake/Clutch Symbol Lt |
| 13 | 532 43 75-46 | Decal Bagger |
| 14 | 532 15 97-36 | Decal Chassis Hot Muffler |
| 15 | 532 43 74-82 | Decal Engine HP |
| 17 | 532 14 08-37 | Decal Saddle Brake Parking |
| 20 | 532 44 09-01 | Decal Bypass Fender CRD |
| 21 | 532 44 11-89 | Decal Hex Belt Sch 92 CRD |
| - - | 532 44 27-44 | Decal, Battery Door |
| - - | 532 42 59-28 | Pad Footrest RH |
| - - | 532 42 59-76 | Pad Footrest LH |
| - - | 532 44 10-84 | Manual Operator's (Euro) |

## WHEELS & TIRES




wheel_1

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 05 91-92 | Cap Valve Tire |
| 2 | 532 06 51-39 | Stem Valve |
| 3 | 532 10 62-22 | Tire F Ts 15 x 6 0 - 6 Service |
| 4 | 532 05 99-04 | Tube Inner Front #35060 |
| 5 | 532 13 83-36 | Rim Asm 6" Front Silver Service |
| 6 | 532 12 49-57 | Fitting Grease |
| 7 | 532 12 49-59 | Bearing Flange |
| 8 | 532 13 83-37 | Rim Asm 8" Rear Silver Service |
| 9 | 532 42 05-31 | Tire R Ts 20 x 10-8 Service |
| 10 | 532 12 49-26 | Tube Rear 9 5 x 8 Service |
| 11 | 532 17 50-39 | Cap Axle Blk 1 50 x 1 00 |
| - - | 532 14 43-34 | Sealant, Tire (10 oz. Tube) |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## SCHEMATIC 38

SCH17




NOTE

YOUR TRACTOR IS EQUIPPED WITH A SPECIAL ALTERNATOR SYSTEM. THE LIGHTS ARE NOT CONNECTED TO THE BATTERY, BUT HAVE THEIR OWN ELECTRICAL SOURCE. BECAUSE OF THIS, THE BRIGHTNESS OF THE LIGHTS WILL CHANGE WITH ENGINE SPEED. AT IDLE THE LIGHTS WILL DIM. AS THE ENGINE SPEED IS INCREASED, THE LIGHTS WILL BECOME THEIR BRIGHTEST.




IGNITION SWITCH

| POSITION | CIRCUIT "MAKE" |
|---|---|
| OFF | M+G+A1 |
| RUN/OVERRIDE | B+A1 |
| RUN | B+A1 L+A2 |
| START | B + S + A1 |



CHASSIS HARNESS CONNECTOR (C1) (MATING SIDE)



DASH HARNESS CONNECTOR (C1) (MATING SIDE)

WIRING INSULATED CLIPS NOTE: IF WIRING INSULATED CLIPS WERE REMOVED FOR SERVICING OF UNIT, THEY SHOULD BE RE-INSTALLED TO PROPERLY SECURE YOUR WIRING.

NON-REMOVABLE CONNECTIONS

REMOVABLE CONNECTIONS

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## ELECTRICAL 32



| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 43 71-57 | Battery |
| 2 | 532 44 09-23 | Screw Hex Head Cap M6 x 1.12 mm |
| 16 | 532 17 61-38 | Switch Interlock Push-In |
| 21 | 532 40 02-52 | Harness Socket Light w/4152J |
| 22 | 532 00 41-52 | Bulb Light |
| 25 | 532 43 71-62 | Cable Starter |
| 26 | 532 17 51-58 | Fuse |
| 27 | 873 51 04-00 | Nut Keps Hex 1/4-20 unc |
| 28 | 532 43 71-63 | Cable, Ground |
| 29 | 532 40 15-45 | Switch, Seat |
| 30 | 532 19 33-50 | Switch, Ign. |
| 33 | 532 41 19-35 | Key/Chain |
| 34 | 532 11 07-12 | Switch Light/Reset |
| 40 | 532 42 10-02 | Harness Ign. Dash |
| 41 | 817 72 04-08 | Screw 1/4-20 x 1/2 |
| 43 | 532 19 25-07 | Solenoid |
| 55 | 817 06 05-12 | Screw Thdrol. 5/16-18 x 3/4 TYTT |
| 71 | 532 44 08-19 | Harness Chassis |
| 79 | 532 17 52-42 | Socket Asm. Bulb Twistlock |
| 83 | 532 43 67-74 | Nut Square M6 x 1.8.5 x 11 mm |
| 87 | 532 42 10-60 | Switch Interlock Clutch Cable |
| 102 | 532 40 44-54 | Harness Pigtail |
| 105 | 532 40 75-68 | Switch Reversing |
| 107 | 532 18 03-79 | Switch Full Bagger Indicator |
| 108 | 532 42 10-62 | Switch Snapmount |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## CHASSIS AND ENCLOSURES 39



# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## CHASSIS AND ENCLOSURES 39

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 5 | 532 40 95-97 | Dash |
| 14 | 532 44 12-87 | Hood |
| 18 | 532 42 65-11 | Grille |
| 34 | 532 44 72-53 | Plate Engine |
| 36 | 817 06 05-12 | Screw 5/16-18 x 3/4 |
| 37 | 532 44 22-31 | Fender |
| 52 | 873 68 05-00 | Nut Crownlock 5/16-18 |
| 68 | 817 49 05-08 | Screw Thdrol. 5/16-18 x 1/2 |
| 130 | 532 41 63-58 | Screw #10 x .750 BOS Thread |
| 150 | 532 40 02-67 | Air Duct |
| 151 | 532 18 75-68 | Bracket Pivot |
| 152 | 532 19 95-35 | Shield Browning |
| 153 | 532 44 42-64 | Lens |
| 156 | 872 14 06-14 | Bolt 3/8-16 unc x 1-3/4 |
| 159 | 817 00 06-12 | Screw 3/8-16 x 3/4 |
| 162 | 532 14 24-32 | Screw Hex Wsh. Hi-Lo 1/4 x 1/2 unc |
| 171 | 532 44 12-89 | Extension Bagger Full |
| 175 | 532 19 94-72 | Crossmember |
| 176 | 532 40 07-76 | Screw 10-24 x 5/8 |
| 177 | 532 19 52-28 | Bushing Steering |
| 179 | 532 16 89-37 | Nut Push |
| 180 | 532 43 54-72 | Chassis |
| 182 | 532 40 71-76 | Dash Lower |
| 183 | 874 52 05-20 | Bolt 5/16-18 x 1-1/4 |
| 189 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 191 | 532 41 65-02 | Insert Reflective RH |
| 194 | 873 90 05-00 | Nut Lock Hex Flange 5/16-18 |
| 199 | 532 41 87-39 | Plate Deck Lift |
| 202 | 532 42 33-17 | Vent Side Hood RH |
| 203 | 532 42 33-16 | Vent Side Hood LH |
| 213 | 874 76 05-12 | Bolt Hex HD 5/16-18 unc 3/4 |
| 217 | 532 40 91-67 | Rod Pivot Hood |
| 218 | 532 19 63-95 | X-Piece Hood Stop |
| 225 | 532 44 14-87 | Bumper Grille |
| 228 | 532 19 51-61 | Stud Fastener |
| 235 | 532 40 61-29 | Spacer Fender |
| 236 | 873 93 05 00 | Nut Center Lock 5/16-18 unc |
| 237 | 532 40 37-04 | Plug Mount Cargo |
| 282 | 532 41 41-10 | Clip Retainer |
| 283 | 532 44 03-61 | Console Deck Lift |
| 284 | 532 44 12-92 | Console Shift RH |
| 287 | 817 60 04-06 | Screw Hex Washead. 1/4-20 x 3/8 |
| 297 | 532 40 18-27 | Insert Reflective LH |
| 308 | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 |
| 309 | 532 43 66-26 | Backplate |
| 310 | 532 44 66-36 | Bracket Hangbar Bag LH |
| 311 | 532 44 66-37 | Bracket Hangbar Bag RH |
| 319 | 532 17 46-62 | Bracket Actuator Bagger |
| 338 | 532 43 66-40 | Bolt Shoulder |
| 339 | 532 43 66-41 | Lever Bagger Full |
| 340 | 532 44 09-31 | Door Battery Tray |
| 341 | 532 43 66-38 | Latch Batter Tray |
| 342 | 532 43 59-38 | Support Fender |
| 343 | 532 44 07-49 | Clip |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## DRIVE 40




drive-tex CRD_K46_fender_8

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21
## DRIVE 40

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | – – – – – – | Transaxle, Tufftorq K46DC (448355) (Order parts from transaxle manufacturer.) |
| 2 | 532 12 35-83 | Key Square |
| 6 | 532 12 42-08 | Bushing Snap |
| 15 | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga. |
| 17 | 532 43 62-27 | Spring, Brake |
| 22 | 532 44 32-46 | Rod Shift |
| 23 | 532 13 05-64 | Knob |
| 29 | 532 43 58-81 | Rod, Brake |
| 33 | 812 00 00-01 | Ring E |
| 35 | 532 40 10-31 | Rod, Brake, Park |
| 37 | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga. |
| 38 | 532 16 96-13 | Nyliner Snap In |
| 42 | 532 12 48-72 | Cover, Foot Pedal |
| 49 | 872 11 06-14 | Bolt 3/8-16 x 1-3/4 Gr. 5 |
| 50 | 532 19 43-27 | Pulley Idler Flat |
| 51 | 873 90 06-00 | Lock Nut 3/8-16 |
| 52 | 532 19 43-26 | Idler Groove |
| 56 | 532 44 18-34 | V-Belt, Drive |
| 61 | 532 43 77-88 | Pulley Transaxle |
| 64 | 532 19 62-00 | Shaft Asm. Pedal Brake Control |
| 73 | 874 49 05-56 | Bolt Hex 5/16-18 x 2-1/2 G5 |
| 90 | 532 44 36-05 | Keeper Belt Clutching |
| 99 | 532 44 39-47 | Rod Spring Bypass |
| 103 | 873 35 05-00 | Nut Hex Jam 5/16-18 unc |
| 116 | 873 90 05-00 | Nut Lock Hex Flange 5/16-18 |
| 125 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 126 | 532 16 60-02 | Washer Srrtd. 5/16 ID x 1 x .125 |
| 140 | 810 04 04-00 | Washer Lock 1/4 |
| 141 | 819 09 12-10 | Washer 9/32 x 3/4 x 10 Ga. |
| 143 | 817 49 05-08 | Screw Thdrol 5/16-18 x 1/2 |
| 159 | 876 02 04-12 | Pin Cotter 1/8 x 3/4 |
| 160 | 532 16 94-84 | Retainer Clip |
| 161 | 532 10 57-09 | Spring, Return, Clutch |
| 165 | 532 19 62-12 | Nyliner |
| 166 | 532 42 91-64 | Nut Push .625 |
| 167 | 532 40 52-57 | Latch Brake Parking |
| 174 | 532 19 72-89 | Nut Push |
| 175 | 532 44 18-23 | Shaft Asm Shift |
| 183 | 532 13 70-57 | Spacer Axle |
| 184 | 532 44 14-07 | Handle Parking Brake |
| 185 | 872 11 06-22 | Bolt 3/8-16 x 2-3/4 |
| 186 | 532 19 43-21 | Spacer Retainer |
| 188 | 532 19 43-23 | Link Clutch Ground Drive |
| 189 | 532 43 36-11 | Bellcrank Ground Drive |
| 195 | 532 43 58-65 | Bracket Rod Brake |
| 203 | 819 11 11-16 | Washer 11/32 x 11/16 x 16 |
| 205 | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga. |
| 221 | 532 40 31-87 | Retainer Spring |
| 226 | 532 40 15-64 | Bracket Mount Torque |
| 227 | 817 49 05-12 | Screw Thdrol 5/16-18 x 3/4 |
| 263 | 817 00 06-12 | Screw Thdr 3/8-16 x 3/4 |
| 268 | 532 18 24-02 | Guard Muffler |
| 275 | 819 13 16-14 | Washer 13/32 x 1 x 14 |
| 279 | 532 44 42-83 | Link Shift |
| 280 | 819 11 10-12 | Washer 11/32 x 5/8 x 12 Ga. |
| 309 | 532 16 55-81 | Plate Fstnr. Cross |
| 311 | 532 16 98-45 | Washer Nylon |
| 312 | 532 16 56-14 | Hub Tapered |
| 313 | 874 78 04-16 | Bolt Hex Fin 1/4-20 unc x 1 Gr. 5 |
| 314 | 532 44 47-13 | Keeper Belt |
| 315 | 817 58 05-20 | Screw Thdrol 5/16-18 x 1.25 |
| 319 | 532 43 67-94 | Spacer Transaxle |
| 320 | 532 18 76-90 | Washer Spacer |
| 328 | 532 43 57-58 | Shaft Shift Front |
| 330 | 532 16 95-93 | Washer Nyliner |
| 331 | 532 44 36-06 | Hub Shift |
| 333 | 532 17 08-68 | Washer Spring Wave |
| 335 | 532 19 95-34 | Idler V Pulley Grnd. Dr. |
| 337 | 532 43 59-37 | Bracket Support Shift |
| 339 | 532 43 68-67 | Strap Torque |
| 348 | 532 44 36-07 | Arm Clevis Rod |
| 350 | 532 44 50-20 | Spring Torsion |
| 351 | 532 43 69-98 | Bracket Deck Sway |
| 352 | 532 43 58-19 | Bracket Idler |
| 353 | 532 43 65-77 | Bracket Idler RH |
| 354 | 817 49 05-10 | Screw 5/16-18 x 5/8 |
| 355 | 532 43 56-69 | Bracket |
| 356 | 532 44 64-41 | Link Shift Cross Shaft |
| 360 | 532 44 47-14 | Nut |
| 362 | 532 43 68-12 | Idler Flat |
| 364 | 532 44 30-32 | Bracket Idler |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21
## ENGINE 24




engine-tex-BS_39

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | – – – – – – | Engine Briggs Model 31E777-2439-B1 (438586) (Order parts from engine manufacturer) |
| 2 | 532 18 86-55 | Muffler |
| 9 | 532 19 43-20 | Keeper Belt Engine |
| 12 | 532 40 54-71 | Pulley Engine |
| 15 | 532 40 75-45 | Tank Fuel 1.5 |
| 18 | 532 43 02-20 | Cap Fuel |
| 20 | 532 18 38-97 | Control Throttle |
| 21 | 532 41 63-58 | Screw #10 x 0.750 BOS Thread |
| 22 | 532 19 49-81 | Control Choke |
| 28 | 532 13 70-40 | Fuel Line |
| 29 | 532 13 71-80 | Spark Arrester Kit |
| 37 | 532 12 34-87 | Clamp Hose |
| 42 | 810 04 07-00 | Lock Washer Hvy. 7/16 |
| 45 | 873 51 04-00 | Nut Keps Hex 1/4-20 unc |
| 69 | 532 16 52-91 | Gasket |
| 79 | 532 19 23-34 | Screw Socket HD 5/16-18 x .75 |
| 84 | 817 06 06-20 | Screw 3/8-16 x 1 |
| 85 | 532 17 39-37 | Bolt Hex 7/16-20 x 4 x Gr. 5-1.5 Thr |
| 87 | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems. |
| 90 | 817 00 06-16 | Screw 3/8-16 x 1 |
| 94 | 581 88 09-01 | Tube Exhaust |
| 96 | 819 09 14-16 | Washer 9/32 x 7/8 x 16 Ga. |
| 97 | 817 67 04-12 | Screw 1/4-20 x 3/4 |
| 102 | 817 06 05-16 | Screw 5/16-18 x 1 |
| 108 | 532 42 30-41 | Cover Pulley |
| 122 | 532 42 19-22 | Extension Drain Oil |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

**Engine Power Rating Information**

The gross power rating for individual gas engine models is labeled in accordance with SAE (Society of Automotive Engineers) code J1940 (Small Engine Power & Torque Rating Procedure), and rating performance has been obtained and corrected in accordance with SAE J1995 (Revision 2002-05). Torque values are derived at 3060 RPM; horsepower values are derived at 3600 RPM. Actual gross engine power will be lower and is affected by, among other things, ambient operating conditions and engine-to-engine variability. Given both the wide array of products on which engines are placed and the variety of environmental issues applicable to operating the equipment, the gas engine will not develop the rated gross power when used in a given piece of power equipment (actual “on-site” or net power). This difference is due to a variety of factors including, but not limited to, accessories (air cleaner, exhaust, charging, cooling, carburetor, fuel pump, etc.), application limitations, ambient operating conditions (temperature, humidity, altitude), and engine-to-engine variability. Due to manufacturing and capacity limitations, Briggs & Stratton may substitute an engine of higher rated power for this Series engine.

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## STEERING ASSEMBLY 41



# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## STEERING ASSEMBLY 41

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 19 46-37 | Wheel, Steering Husq SR |
| 2 | 532 41 35-91 | Axle Asm., Front |
| 4 | 532 40 30-87 | Spindle Asm., LH |
| 5 | 532 40 30-88 | Spindle Asm., RH |
| 6 | 532 12 49-31 | Bearing, Race Thrust Hardened |
| 7 | 532 12 17-48 | Washer 25/32 x 1-5/8 x 16 Ga. |
| 8 | 812 00 00-29 | Ring, Clip #T5304-75 |
| 9 | 532 12 12-32 | Cap, Spindle |
| 13 | 532 12 17-49 | Washer 25/32 x 1-1/4 x 16 Ga. |
| 14 | 810 04 06-00 | Washer, Lock Hvy. Hlcl. Spr. 3/8 |
| 15 | 873 54 06-00 | Nut, Crown Lock 3/8-24 unf |
| 16 | 532 42 93-73 | Shaft Steering |
| 19 | 532 19 47-29 | Plate Steering |
| 20 | 532 40 97-63 | Boot, Steering |
| 21 | 532 18 67-37 | Adapter, Wheel Steering |
| 22 | 532 42 05-37 | Supt., Strg. Lower |
| 26 | 532 19 46-03 | Insert, Wheel Steering Husq SR |
| 28 | 817 00 06-12 | Screw 3/8-16 x 3/4 |
| 33 | 810 04 05-00 | Washer Lock 5/16 |
| 35 | 532 19 47-32 | Gear, Sector Plate |
| 45 | 819 11 38-12 | Washer 11/32 x 3/8 x 12 Ga. |
| 53 | 532 18 89-67 | Washer Hardened .793 x 1.637 x .060 |
| 57 | 532 40 74-65 | Bracket Upstop |
| 58 | 532 19 47-47 | Bolt Shoulder Sector Pivot CFM |
| 59 | 532 19 47-48 | Washer Thrust Sector Steering |
| 60 | 873 97 10-00 | Nut Flange Lock 5/8-11 |
| 61 | 532 19 47-40 | Draglink, LH |
| 62 | 532 19 47-41 | Draglink, RH |
| 63 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 64 | 532 19 98-49 | Retainer Clip Spring Steering |
| 66 | 871 02 07-48 | Bolt Hex Fghd. 7/16-14 x 3 Serr. |
| 67 | 532 19 47-37 | Bushing PM Front Axle |
| 68 | 873 90 07-00 | Nut Lock Flange 7/16-14 Gr. 5 |
| 69 | 532 19 91-62 | Washer 1.5 x .505 x .118 |
| 70 | 532 19 61-97 | Bracket Deck Susp. Front |
| 71 | 532 19 07-52 | Shaft Extension Steering |
| 72 | 532 42 89-82 | Bolt Fin Hx 5/16-18 x 4 w/Patch |
| 118 | 532 40 60-13 | Bushing Axle Cast |
| 122 | 532 44 49-62 | Cap Gear |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## MOWER DECK 44




tex-deck_CRD_3_r3

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## MOWER DECK 44

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 43 69-70 | Deck Weldment |
| 3 | 873 90 05-00 | Nut Lock Hex Flange 5/16 - 18 |
| 5 | 817 00 05-10 | Bolt 5/16-18 |
| 7 | 532 41 63-58 | Screw #10 x 0.750 BOS Thread |
| 11 | 532 13 77-29 | Screw Thd Roll 1/4 - 20 X 5/8 |
| 13 | 872 11 06-12 | Bolt Carr Sh 3/8 - 16 X 1 - 1/2 Gr. 5 |
| 14 | 532 15 60-85 | Keeper Belt Idler |
| 16 | 873 90 06-00 | Nut Lock FIG 3/8 - 16 unc |
| 17 | 532 40 02-34 | Nut Flange Lock Top |
| 18 | 532 18 76-90 | Washer Spacer Mandrel |
| 19 | 532 11 04-85 | Bearing Ball Mandrel |
| 20 | 532 17 39-84 | Screw Thread Roll |
| 23 | 817 49 06-28 | Screw Thdrol 3/8 - 16 X 1-3/4 |
| 10 | 817 00 06-16 | Screw 3/8-16x1 smgml tap |
| 27 | 532 43 97-26 | V-Belt Drive |
| 32 | 532 40 18-72 | Spring Return Deck |
| 33 | 532 18 72-81 | Housing Mandrel 4pt Service |
| 34 | 532 19 28-72 | Shaft Asm Mndrl N/Greaseable38 |
| 35 | 532 42 79-84 | Blade Mower LH |
| 36 | 532 19 30-03 | Bolt/Washer Asm 7/16 - 20 unf |
| 37 | 819 13 13-16 | Washer 13/32 x 13/16 x 16 Ga. |
| 40 | 532 19 72-58 | Keeper Belt Engine LH |
| 42 | 817 00 05-12 | Screw 5/16-18 x 3/4 |
| 43 | 532 19 74-73 | Pulley Mandrel |
| 45 | 532 13 71-52 | Housing Mandrel |
| 67 | 532 40 30-12 | Handle Clutch Cable |
| 70 | 532 40 12-46 | Clutch Asm Manual LT Pred |
| 71 | 817 67 06-08 | Screw Thdrol 3/8-16 x 1/2 |
| 72 | 532 44 68-10 | Chute Upper |
| 75 | 532 13 14-94 | Pulley Idler Flat |
| 76 | 532 43 96-40 | Washout Port |
| 84 | 532 43 25-20 | Keeper Belt LH Mandrel |
| 85 | 532 42 79-85 | Blade Mower RH |
| 86 | 532 18 17-13 | Bolt 3/8-24 x 1.50 Gr. 8 |
| 87 | 810 03 06-00 | Washer Lock Hvy 3/8 |
| 88 | 532 14 02-96 | Washer Hard Blade Mower Vented |
| 89 | 532 43 81-24 | Arm Brake 97 LH |
| 90 | 532 19 90-92 | Spacer Retainer |
| 91 | 819 13 20-12 | Washer 13/32 x 1-1/4 x 12 Ga. |
| 92 | 532 43 69-93 | Rod Brake |
| 93 | 532 43 81-25 | Arm Brake RH |
| 94 | 532 19 72-50 | Bracket Clutch Cable |
| 95 | 817 00 06-12 | Screw 3/8-16 x 3/4 |
| 96 | 532 40 02-71 | Spacer |
| 97 | 532 18 20-61 | Shield Idler Mower |
| 98 | 532 19 51-61 | Stud Fastener |
| 99 | 532 19 51-86 | Arm Suspension Mower Rear |
| 100 | 532 19 65-39 | Bolt Shoulder |
| 101 | 873 68 09-00 | Nut Crownlock 9/16 - 18 unc |
| 102 | 532 40 25-11 | Spacer Bearing Swing Plate |
| 103 | 532 43 69-92 | Guard Front Vent |
| 104 | 532 44 14-79 | Mandrel Cover RH |
| 105 | 532 44 14-78 | Mandrel Cover LH |
| 106 | 532 19 32-16 | Spring Brake Return |
| 110 | 532 41 53-56 | Gear Output |
| 111 | 532 43 69-79 | Gasket Gearcase |
| 112 | 532 44 38-52 | Shaft Gearcase |
| 113 | 532 43 85-33 | Plug Oil |
| 114 | 532 43 85-34 | Valve Relief |
| 115 | 818 03 10-16 | Screw Torx #10-24 x 1 |
| 116 | 872 11 04-14 | Bolt 1/4-20 x 1.75 Gr. 5 |
| 117 | 873 90 04-00 | Nut Hex Flange 1/4-20 unc |
| 118 | 532 43 69-89 | Arm Clutching |
| 119 | 532 43 81-66 | Gearcase Subasm |
| 120 | 532 43 69-91 | Keeper Belt RH |
| 121 | 532 43 69-85 | Washer |
| 124 | 532 43 69-86 | Non Greasable Mandrel Shaft |
| 125 | 532 43 69-94 | Bracket Idler Chasses |
| 127 | 532 19 34-06 | Bolt Shoulder 3/8-16 x 3-5/8 Gr. 5 |
| 128 | 532 17 48-73 | Wheel Guage |
| 129 | 532 40 48-51 | Rod Anti-Sway |
| 130 | 819 13 13-12 | Washer 13/32 x 13/16 x 12 Ga. |
| 131 | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |
| 132 | 532 17 88-99 | Knob Handle |
| 136 | 532 43 96-39 | Washout Port Hookup |
| 137 | 812 00 00-29 | Ring Klip |
| 138 | 532 44 07-43 | Hose 3/8 Long 12" |
| 139 | 532 44 07-42 | Hose 3/8 Clamp |
| 140 | 532 44 86-32 | Guard Asm LH |
| 141 | 532 44 85-30 | Guard Asm RH |
| 152 | 532 44 04-88 | Cable Clutch Manual w/Spring |
| 159 | 872 14 06-14 | Bolt |
| 160 | 532 16 89-37 | Washer |
| - - | 532 19 28-70 | Mandrel Assembly (Includes Housing, Shaft Assembly, And Bearing Only - Pulley/Nut/Washer And Blade Bolt/Washers Not Included) |
| - - | 532 44 14-23 | Replacement Mower Complete |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## MOWER LIFT 45




| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 2 | 532 43 69-96 | Deck Lift Weldment |
| 3 | 532 19 52-31 | Lever Asm., Lift RH |
| 7 | 532 41 15-55 | Grip, Lever |
| 10 | 532 19 63-14 | Spring Torsion |
| 87 | 532 19 42-09 | Pin Cotter 7/16 Bow Tie Lock |
| 88 | 532 43 69-95 | Spring Lift Assist |
| 89 | 819 19 19-12 | Washer Clear Zinc |
| 90 | 532 19 42-08 | Pin Cotter 5/16 Bow Tie Lock |

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 91 | 532 19 51-81 | Link Lift Susp. Mower Rear |
| 97 | 817 49 06-08 | Screw 3/8-16 x 1/2 |
| 98 | 532 19 52-70 | Link Lift Susp. Front Mower |
| 100 | 873 93 06-00 | Nut Centerlock 3/8-16 |
| 101 | 532 40-70-03 | Link Asm. Lift FXD |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## SEAT ASSEMBLY 42




| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 41 14-05 | Seat |
| 2 | 532 18 01-66 | Bracket Pivot Fender |
| 3 | 532 14 06-75 | Strap, Asm. Fender |
| 6 | 873 80 06-00 | Nut, Lock w/Ins. 3/8-16 unc |
| 7 | 532 12 41-81 | Spring, Seat Cprsn. |
| 8 | 532 17 18-77 | Bolt 5/16-18 unc x 3/4 w/Sems. |
| 10 | 532 19 69-77 | Pan, Seat |
| 21 | 532 17 18-52 | Bolt, Shoulder 5/16-18 |

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 37 | 873 80 05-00 | Nut, Lock 5/16-18 unc |
| 40 | 532 19 76-61 | Handle |
| 41 | 532 19 82-00 | Spring |
| 43 | 874 76 06-12 | Bolt 3/8-16 unc x 3/4 |
| 44 | 819 13 38-12 | Washer 13/32 x 2-3/8 x 12 Ga. |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm

# TRACTOR - MODEL NO. LT2317 CMA (96051002100), PROD. NO. 960 51 00-21

## BAGGER 46



## BAGGER 46

| KEY NO. | PART NO. | DESCRIPTION |
|---|---|---|
| 1 | 532 42 86-10 | Tube Handle Bagger |
| 4 | 532 43 96-12 | Frame Asm Bagger Top |
| 5 | 532 41 76-32 | Frame Asm Top Bagger |
| 6 | 532 12 68-75 | Rivet Drilled |
| 7 | 873 90 04-00 | Nut Hex Flange 1/4-20 unc |
| 8 | 532 42 59-54 | Cover Bagger |
| 9 | 532 41 76-29 | Insert Handle Bagger |
| 10 | 532 43 67-70 | Frame Front |
| 11 | 532 43 67-71 | Tubing Brace Bagger |
| 12 | 532 42 17-93 | Nut Square 1/4 |
| 13 | 532 42 17-80 | Screw 1/4 x 1.150 |
| 14 | 532 42 18-00 | Bolt Shoulder 1/2 x 1.150 |
| 19 | 532 19 42-08 | Cotter Pin 5/16 Bow Tie |
| 20 | 585 36 88-01 | Screw Hex Cap 1/4-20 x 1.375 |
| 21 | 532 43 70-06 | Bag Asm |
| 23 | 872 04 04-10 | Bolt Carr. 1/4-20 |
| 25 | 532 42 16-14 | Spring Latch |
| 26 | 817 49 04-12 | Screw 1/4-20 x 3/4 |
| 27 | 532 42 12-62 | Grommet Rubber |
| 28 | 532 16 57-87 | Grip Handle Black |
| 30 | 532 43 74-52 | Plug |
| 31 | 532 43 58-61 | Pin Hinge |
| 32 | 532 43 74-54 | Spring Double Torsion |
| 33 | 532 43 84-51 | Shaft Mulch Plug |
| 34 | 532 43 79-88 | E-Ring 5/16 |
| 35 | 532 43 91-39 | Grip Mulch Plug |
| 36 | 532 43 90-98 | Bolt J |
| 37 | 532 06 91-80 | Nut Lock #10-24 unc |
| 38 | 819 07 08-18 | Washer 7/32 x 1/2 |
| 39 | 532 43 92-42 | Bungee |
| 40 | 532 43 94-18 | Support Bagger Corner RH |
| 41 | 532 43 94-35 | Support Bagger Corner LH |
| 42 | 532 44 04-28 | Christmas Tree Clip |

**NOTE:** All component dimensions given in U.S. inches
1 inch = 25.4 mm